


INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Remove socket ring (A) from socket (B), place shade (C) onto the threaded section of socket (B) and secure with socket ring (A).
- 2. Insert light bulb (not included) into socket.
- 3. Remove plastic cover (E) from electrical plug (D).
- 4. Plug lamp into electrical outlet.

UNPACKING NOTICE



Swing Table Lamp

Item # BBL3070

THE FOLLOWING INSTRUCTIONS SHOULD BE READ PRIOR TO UNPACKING YOUR PRODUCT AS THEY ARE INTENDED TO REDUCE OR ELIMINATE ANY POSSIBLE DAMAGE.

Warning: To prevent any damange to the lamp, use the index and thumb at the top left (A) and top right (B) corners. Pivot the lamp so the rod is the highest point of the lamp before removal and then lift to remove the lamp from the box.