

T-Bar Connector

700MOTBAR_ 1.8




SPECIAL INSTALLATION


GENERAL PRODUCT INFORMATION:



This product is used with rigid and adjustable MonoRail standoffs.




Install the T-Bar Connector




- 1 Select the locations on the grids where the standoffs will be mounted.
- 2 Push the T-bar connector flat section against the grid. Rotate the T-bar connector until the tabs on the T-bar connector snap behind the grid.

Install the 2" Rigid Standoff



- 1 Screw the nipple to the threaded stud.
- 2 Screw the adapter post completely to the nipple.
- 3 Push the housing nipple onto the standoff adapter and tighten the #6-32 set screw on the housing nipple snugly with the 1/16 Allen wrench.
- 4 Put the MonoRail into the housing.
- 5 Loosen the #6-32 set screw on the housing nipple so that it can turn easy.
- 6 Screw the housing nipple to the housing tight by turning the housing nipple clockwise.
- 7 Tighten the #6-32 set screw on the housing nipple with the 1/16 Allen wrench.


Install the Rigid Standoff



- 1 Screw the nipple to the threaded stud.
- 2 Screw the standoff post completely to the nipple.
- 3 Push the standoff rod completely into the standoff post and tighten the #6-32 set screw with the 1/16 Allen wrench.
- 4 Push the housing nipple onto the standoff rod and tighten the #6-32 set screw on the housing nipple snugly with the 1/16 Allen wrench.
- 5 Put the MonoRail into the housing.
- 6 Loosen the #6-32 set screw on the housing nipple so that it can turn easy.
- 7 Screw the housing nipple to the housing tight by turning the housing nipple clockwise.
- 8 Tighten the #6-32 set screw on the housing nipple with the 1/16 Allen wrench.

SAVE THESE INSTRUCTIONS!

Install the Adjustable standoff



- 1 Screw the nipple to the threaded stud.
- 2 Screw the cable post completely to the nipple.
- 3 Feed the aircraft cable into the cable post and tighten the #6-32 set screw with the 1/16 Allen wrench.
- 4 Feed the aircraft cable into the wire grip by pushing the tab down and pulling the cable from the side hole of the post.
- 5 Loosen the #6-32 set screw on the housing nipple with the 1/16 Allen wrench so that it can turn easily.
- 6 Place the MonoRail into the housing and screw the housing nipple to the housing tight.
- 7 Tighten the #6-32 set screw with the 1/16 Allen wrench and trim off excess aircraft cable.



7400 Linder Ave, Skokie, IL 60077

847.410.4400

www.techlighting.com

© 2008 Tech Lighting, L.L.C. All rights reserved. The "Tech Lighting" graphic is a registered trademark of Tech Lighting, L.L.C. Tech Lighting reserves the right to change specifications for product improvements without notification.

A Generation Brands Company